



# Assembly Instructions



1 IF LOCKED UNLOCK HARD CASE.



2 OPEN BOTH LATCHES ON THE HARD CASE



3 REMOVE UNIT FROM HARD CASE



4 REMOVE BUBBLE WRAP FROM UNIT



5 WHILE HOLDING DOWN THE BASE LIFT TOP SECTION OF THE UNIT .



6 POSITION LOCKING PIN AT BOTTOM OF BASE PRIOR TO USING UNIT.



7 SWING OPEN FLAP ON THE BOTTOM SECTION. (MAKE SURE TO FLIP BOTTOM SECTION FLAP FLAT ONTO GLASS BEFORE ATTEMPTING TO RETRACT.)

TO COLLAPSE THE UNIT, REPEAT SETUP INSTRUCTIONS IN REVERSE. BE CAREFUL RETRACTING UNIT



PIN SET IN FIRST GROVE



PIN SET IN SECOND GROVE



PIN SET IN THIRD GROVE